

## BOSCH – kosiarki (*lawn mowers*)

producent	model	nr kat.	ean	uwagi	ilość
Bosch	Advanced ROTAK 690			nowa ( <i>new</i> ), złamany uchwyt ( <i>broken handle</i> )	1
Bosch	Advanced ROTAK 36-660	06008B9606	4059952526867	nowa ( <i>new</i> ), 2 x 2,0 Ah (2021)	1
Bosch	Advanced ROTAK 36-660	06008B9606	4059952526867	nowa ( <i>new</i> ), złamany uchwyt ( <i>broken handle</i> ) 2 x 2,0 Ah (2021)	2
Bosch	Universal ROTAK 36-550	06008B9506	4059952526775	używana ( <i>used</i> ), bez baterii ( <i>no battery</i> ), bez ładowarki ( <i>no charger</i> )	1
Bosch	Universal ROTAK 36-550	06008B9506	4059952526775	używana ( <i>used</i> ), 1 x 4,0 Ah (2021)	1
Bosch	Universal ROTAK 36-550	06008B9506	4059952526775	nowa ( <i>new</i> ), bez baterii ( <i>no battery</i> ), bez ładowarki ( <i>no charger</i> )	1
Bosch	Easy ROTAK 36-550	06008B9B00	4059952505497	używana ( <i>used</i> ), 1 x 4,0 Ah (2021)	1
Bosch	ARM 37			nowa ( <i>new</i> ), złamany uchwyt ( <i>broken handle</i> )	1